

Aquablanc

O₂ Tablets & A Combination Liquid



Key Features

- A popular chlorine-free system
- Simple 2-part chlorine-free system
- Low odour
- Gentle approach to water care

Ideal O₂ (MPS) range: 5 – 8mg/l

Before converting a hot tub to the Aquablanc oxygen system, it is recommended that the hot tub is drained and re-filled with fresh water. The hot tub should then be shock dosed with chlorine.

Application Instructions

1. Maintain pH level within the ideal range of 7.2 – 7.6. If not in this range, adjust.
2. **Aquablanc A Combination Liquid**
Apply Aquablanc A Combination Liquid directly to the hot tub water with the filtration running.
Initial Dose: Add 60ml per 1,500 litres of hot tub water.
Weekly: Add 15ml per 1,500 litres of hot tub water.
3. **Aquablanc O₂ Tablets**
Apply Aquablanc O₂ Tablets via a floating dispenser or hot tub skimmer to prevent bleaching of hot tub surface.
Initial Dose: Add 2 x 20g tablets per 1,500 litres of hot tub water.
Weekly: Add 1 x 20g tablet per 1,500 litres of hot tub water.

Note: A weekly application of AquaSParkle Spa Fusions is recommended.

